20 STERN AVE. SPRINGFIELD, NEW JERSEY 07081 U.S.A.

MR501, MR502, MR504 MR506, MR508, MR510

Designers Data Sheet STANDARD RECOVERY POWER RECTIFIERS MINIATURE SIZE, AXIAL LEAD MOUNTED STANDARD RECOVERY POWER RECTIFIERS 100-1000 VOLTS **3 AMPERE** . . designed for use in power supplies and other applications having need of a device with the following features: High Current to Small Size High Surge Current Capability Low Forward Voltage Drop Void-Free Economical Plastic Package Available in Volume Quantities **Designer's Data for "Worst Case" Conditions** The Designers Data sheets permit the design of most circuits entirely from the information presented. Limit curves - representing boundaries on device character-istics - are given to facilitate "worst case" design. MAXIMUM RATINGS MR MR MB MR 506 MR 508 501 502 504 510 Reting Symbol Unit Peak Repetitive Reverse Voltage VRRM Volts Working Peak Reverse Voltage 100 200 400 600 800 1000 DC Blocking Voltage Non-Repetitive Peak Reverse 150 250 650 1050 Volts 450 850 VRSM Voltage Average Rectified Forward Amp 10 Current (Single phase resistive load, To 3.0 95°C, PC Board Mounting) (1) (EIA Standard Conditions L = 1/32", TL = 85°C) STYLE 1: Non-Repetitive Peak Surge 100 Amp FSM PIN 1. CATHODE 2. ANODE Current (surge applied at (one cycle) rated load conditions) MILLIMETERS -65 to +175 °c Operating and Storage Junction TJ,Tstg លស Temperatura Range (2) THERMAL CHARACTERISTICS Characteristic Sy mbol Max Unit °C/W Thermal Resistance, Junction to Ambient ROJA 28 CASE 267-01 (Recommended Printed Circuit Board Mounting, See Note 2 on Page 4). ELECTRICAL CHARACTERISTICS MECHANICAL CHARACTERISTICS Case: Void Free, Transfer Molded Characteristic Symbol Min Тур Max Unit Finish: External Leads are Plated, Instantaneous Forward Voltage (3) ٧F Volus (iF = 9.4 Amp, Tj = 175°C) 0.9 1.0 Leads are readily Solderable Polarity: Indicated by Cathode Band (ip = 9.4 Amp, Tj = 25°C) 1.04 1.1 Reverse Current (rated dc voltage) (3) Weight: 1.1 Grams (Approximately) 1_R μĀ TJ = 25°C TJ = 100°C 0.1 5.0 Maximum Lead Temperature for 2.8 25 Soldering Purposes: 300°C, 1/8" from case for 10 s (1) Derate for reverse power dissipation. See Note on Page 2. at 5.0 lb. tension (2) Derate as shown in Figure 1. (3) Pulse Test: Pulse Width = 300 µs, Duty Cycle = 2.0%.

N J S

NJ Semi-Conductors reserves the right to change test conditions, parameter limits and package dimensions without notice. Information furnished by NJ Semi-Conductors is believed to be both accurate and reliable at the time of going to press. However, NJ Semi-Conductors assumes no responsibility for any errors or omissions discovered in its use. NJ Semi-Conductors encourages customers to verify that datasheets are current before placing orders.

TELEPHONE: (973) 376-2922 (212) 227-6005 FAX: (973) 376-8960

Quality Semi-Conductors

MR501, MR502, MR504, MR506, MR508, MR510 (continued)

NOTE 1: DETERMINING MAXIMUM RATINGS

Reverse power dissipation and the possibility of thermal runeway must be considered when operating this rectifier at reverse voltages above 200 volts. Proper derating may be accomplished by use of equation (1):

$$T_A(max) = T_J(max) \sim R_{\theta JA}P_F(AV) = R_{\theta JA}P_R(AV)$$
 (1)
where

T_{A(max)} = Maximum allowable ambient temperature

- T_J(max) = Maximum ellowable junction temperature (175°C or the temperature at which thermel runaway occurs, whichever is lowest.)
- PF(AV) = Average forward power dissipation
- PR(AV) = Average reverse power dissipation
- $R_{\theta JA} = Junction-to-embient thermal resistance$

Figure 1 permits easier use of equation (1) by taking reverse power dissipation and thermal runaway into consideration. The figure solves for a reference temperature as determined by equation (2):

TR = TJ(max) - ReJAPR(AV)	(2)
Substituting equation (2) into equation (1) yields:	

 $T_A(max) = T_R - \hat{R}_{\theta J} A^P F(AV) \tag{3}$ Inspection of equations (2) and (3) reveals that T_R is the ambient temperature at which thermal runaway occurs or where $T_J = 175^{\circ}C$,

when forward power is zero. The transition from one boundary condition to the other is evident on the curves of Figure 1 as a difference in the rate of change of the slope in the vicinity of 185° C. The data of Figure 1 is based upon dc conditions. For use in common rectifier circuits, Teble 1 indicates suggested factors for an equivalent dc voltage to use for conservative design; i.e.:

 $V_{R(equiv)} = V_{in}(PK) \times F$ (4)

The Factor F is derived by considering the properties of the various rectifier circuits and the rectifiers reverse characteristics.

Example: Find T_{A(max)} for MR510 operated in a 400 Volt dc supply using a full wave center-tapped circuit with capacitive filter such that $I_{DC} = 6.0 \text{ A}$, $(I_{F(AV)} = 3.0 \text{ A})$, $I_{(PK)}/I_{(AV)} = 10$, input Voltage = 283 V(rms) (line to center tap), $R_{0JA} = 28^{O}C/W$.

- Step 1: Find V_{R(equiv)}. Read F = 1.11 from Table 1 ∴ V_{R(equiv)} = 1.41)(283)(1.11) ~ 444 V
- Step 2: Find T_R from Figure 1. Read T_R = $167^{\circ}C \otimes V_{R} \approx 444 V \& R_{\theta JA} = 28^{\circ}C/W.$
- Step 3: Find P_{F(AV)} from Figure 8. Read P_{F(AV)} = 4 W

Step 4: Find $T_{A(max)}$ from equation (3). $T_{A(max)} = 167-(28)$ (4) = 55°C.

TABLE I - VALUES FOR FACTOR F

Circuit Losd	Half Wave		Full Wave, Bridge		Full Wave Center-Tapped*†	
	Resistive	Cepacitive*	Resistive	Capacitive	Resistive	Capacitive
Sine Wave	0.45	1.11	0.45	0.55	0.90	1.11
Square Wave	0.61	1.22	0.61	0.61	1.22	1.22

^{*}Note that V_{R(PK)} ≈2 V_{in(PK)}

tUse line to center tap voltage for Vin-




FIGURE 2 - FORWARD POWER DISSIPATION

